







Ceiling mount bracket for V7 ultra low-profile vandal domes

DWC-V7CMW



WHAT'S IN THE BOX

Camera Mounting Screws		2	Mounting Pad		1
Screws and Plastic Anchors		4	Mounting Template		1
Hexagonal Wrench		1	Quick Setup Guide		1

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



INSTALLATION

- 1 Using the mounting template or the mounting bracket itself, mark and drill the necessary holes on the mounting surface.
- 2 Secure the mounting bracket to the mounting surface using the screws and anchors included. Use the mounting pad between the bracket's arm and mounting surface as needed.
- 3 To mount the camera to the mounting accessory, remove the dome from the camera base using the wrench included with the camera.

NOTE: Do not touch the lens when handling the camera.

- 4 Pass wires through the mounting bracket and make all necessary connections with the camera.
- 5 Secure the camera's junction box to the mounting bracket using the included camera mounting screws.
- 6 Adjust the camera's position and angle and complete the installation by placing the dome cover on the camera. Secure the dome cover to the camera's base using the screws included with the camera. See the camera's QSG for more information.

